




## WH SS-L5 Topside and Subsea Lever Hoist Spare Parts



Part Code	Part Name
SSL5.01	Gear cover
SSL5.02	Pinion gear
SSL5.03	Pinion shaft
SSL5.04	Load gear
SSL5.05	Gear side plate assembly
SSL5.06	Bearing
SSL5.07	Load sheave
SSL5.08	Chain guide
SSL5.09	Chain stripper
SSL5.10	Lever Side plate assembly
SSL5.11	Stainless Steel Pawl spring
SSL5.12	Pawl spring - Standard
SSL5.13	Circlip
SSL5.14	Disc Hub
SSL5.15	Ratchet gear c/w friction discs
SSL5.16	Brake cover assembly
SSL5.17	Lever Side Plate Nyloc Nut (M6)
SSL5.19	Lever Hoist Cover Nyloc Nut (M8)
SSL5.20	Change gear
SSL5.20L	Load limiter
SSL5.21	Change over pawl
SSL5.22	Change over stand
SSL5.23	Change over spring
SSL5.24	Handle assembly
SSL5.25	Screw
SSL5.25A	Spring Washer
SSL5.26	Cam
SSL5.27	Spring
SSL5.28	Grip ring
SSL5.29	Spring
SSL5.30	Spring housing
SSL5.31	Castle nut
SSL5.32	Split pin
SSL5.35	Chain fixing pin nyloc nut
SSL5.36	Chain fixing pin

SSL5.37	Latch kit
SSL5.38	Bottom hook assembly
SSL5.39	Top hook pin
SSL5.40	Top hook assembly
SSL5.42	Pinion Shaft Washer
SSL5.47	Chain fixing pin 6.3t, 10t top hook
SSL5.48	Nut
SSL5.50	Rubber handle nut
SSL5.50A	Rubber handle bolt
8-064	Travelling End Stop
SSL5.62	Rubber handle with enlarged pommel
RSSL5.63	Label
SSL5.64	Label Rivets